
ELECTRICAL CONNECTION




TRIPLE-R 750 BEACON

Please refer to the instructions included with the lamps.

LAMP CONNECTOR INFORMATION TRIPLE-R POSITION LIGHT FUNCTION (OPTIONAL) **BROWN WIRE GREEN WIRE** AMBER POSITION










UNECE REGULATIONS

Please scan the QR code to view all UNECE Certificates and information.



CANBUS INTEGRATION (SOLD SEPERATELY)

For vehicles where it is not possible to locate a 12V high beam signal, it will be necessary to take the high beam signal from the vehicle's CAN system. For connection options please visit the Lazer Lamps website, or contact your nearest dealer.





TRIPLE-R 750 - FITTING INSTRUCTIONS



We appreciate your purchase of a Lazer Lamps product, and value your feedback. If you would like to leave feedback on your Lazer experience, please head to the relevant product page on our website www.lazerlamps.com.

> T +44 (0) 1992 677374 E sales@lazerlamps.com

Lazer Lamps Ltd, Calder House, Central Road Harlow, Essex, CM20 2ST, UK














WHAT'S INCLUDED

- 4x Grille Mounting Brackets4x Cutting Guides
- Anti-Theft Fasteners & Key
- Fitting Instructions

- Additionally Kit Includes: 2x Triple-R 750 LED Lights
- 1x Two-Lamp Wiring Kit

TOOLS REQUIRED



TORQUE VALUES



INSTALLATION PROCESS - Install should be completed with the grille left on the vehicle.













